


AIRCRAFT PARKING /
DOCKING CHART - ICAO

APRON ELEV 6 m


TWR	118.8	118.2
GND	121.7	121.75
APRON	121.65	122.175 121.8 121.875

SEOUL / Incheon Intl



Change : Information of HS NR, Establishment of HS NR. 64~69 and Withdrawal of ACFT stand NR. 227, 228, 271.

Multiple use stands operation



INS COORDINATES FOR AIRCRAFT STANDS				
		WGS-84		ELEV(AMSL)
231	L	37°27'53.63"N	126°25'52.33"E	6 m
	R	37°27'53.49"N	126°25'54.22"E	6 m
232	L	37°27'50.70"N	126°25'53.65"E	6 m
	R	37°27'50.51"N	126°25'55.53"E	6 m
236	R	37°27'42.18"N	126°26'00.21"E	6 m
239	R	37°27'43.60"N	126°26'03.66"E	6 m
258	R	37°27'57.53"N	126°26'28.40"E	6 m
261	L	37°28'06.75"N	126°26'24.13"E	6 m
	R	37°28'06.14"N	126°26'22.44"E	6 m
267	L	37°28'08.58"N	126°26'21.11"E	6 m
	R	37°28'08.28"N	126°26'19.65"E	6 m
268	L	37°28'10.56"N	126°26'18.63"E	6 m
	R	37°28'10.51"N	126°26'17.04"E	6 m
304	L	37°27'38.98"N	126°26'40.51"E	6 m
	R	37°27'39.74"N	126°26'41.85"E	6 m
306	L	37°27'35.70"N	126°26'34.70"E	6 m
	R	37°27'36.46"N	126°26'36.04"E	6 m
310	L	37°27'30.71"N	126°26'25.87"E	6 m
	R	37°27'31.47"N	126°26'27.22"E	6 m
311	L	37°27'29.03"N	126°26'22.91"E	6 m
	R	37°27'29.79"N	126°26'24.25"E	6 m
341	L	37°28'17.68"N	126°26'22.79"E	6 m
	R	37°28'16.61"N	126°26'23.75"E	6 m
351	L	37°27'53.15"N	126°25'42.29"E	6 m
	R	37°27'54.22"N	126°25'41.34"E	6 m



Stand NR	Availability
231L/R, 232L/R, 266L/R, 267L/R, 268L/R, 304L/R, 306L/R, 310L/R, 311L/R, 341L/R, 351L/R	Available for aircraft up to "C" code.
236R, 239R, 258R, 261R	Available for aircraft up to "F" code.

For details, please contact to confirm with "the Apron Mgmt. Unit" at the telephone number 82-32-741-2991.

Note	Code letter	Wing span
"B": Refer to Annex 14 to the Convention on International Civil Aviation, Volume I, Chapter 1, Table 1-1 "Aerodrome reference code".	E	52 m up to but not including 65 m
	D	36 m up to but not including 52 m
	C	24 m up to but not including 36 m
	B	15 m up to but not including 24 m

Change : Withdrawal of ACFT stand NR. 228.

Multiple use stands operation












Stand NR	Availability
612L/R 801A/B/C/D, 802A/B/C/D, 803L/R, 821L/R, 841A/B/C/D, 851A/B/C/D	Available for all aircraft up to "B" code. [length(overall) up to 32.5 m]
645L/R, 646L/R, 647L/R, 648R, 652L/R, 814A/B, 816A/B	Available for aircraft up to "C" code.
648L, 831L/R	Available for aircraft up to "D" code.

For details, please contact to confirm with "the Apron Magt. Unit" at the telephone number 82-32-741-2991.








Note.	Code letter	Wing span
"B": Refer to Annex 14 to the Convention on International Civil Aviation, Volume I, Chapter 1, Table 1-1 "Aerodrome reference code".	E	52 m up to but not including 65 m
	D	36 m up to but not including 52 m
	C	24 m up to but not including 36 m
	B	15 m up to but not including 24 m

INS COORDINATES FOR AIRCRAFT STANDS				
		WGS-84		ELEV(AMSL)
612	L	37°28'05.21"N	126°28'18.18"E	6m
	R	37°28'04.18"N	126°28'16.78"E	6m
645	L	37°28'21.42"N	126°27'36.56"E	7 m
	R	37°28'20.73"N	126°27'35.34"E	7 m
646	L	37°28'22.78"N	126°27'38.96"E	7 m
	R	37°28'22.09"N	126°27'37.74"E	7 m
647	L	37°28'24.13"N	126°27'41.35"E	6 m
	R	37°28'23.45"N	126°27'40.15"E	7 m
648	L	37°28'26.59"N	126°27'46.05"E	6 m
	R	37°28'25.86"N	126°27'44.13"E	6 m
652	L	37°28'33.02"N	126°27'56.81"E	6 m
	R	37°28'32.21"N	126°27'55.36"E	6 m
801	A	37°28'34.92"N	126°26'07.33"E	5 m
	B	37°28'33.60"N	126°26'08.50"E	5 m
	C	37°28'33.98"N	126°26'05.67"E	5 m
	D	37°28'32.66"N	126°26'06.84"E	5 m
802	A	37°28'33.23"N	126°26'04.34"E	5 m
	B	37°28'31.91"N	126°26'05.52"E	5 m
	C	37°28'32.24"N	126°26'02.58"E	5 m
	D	37°28'30.91"N	126°26'03.76"E	5 m
803	L	37°28'30.04"N	126°26'00.40"E	5 m
	R	37°28'30.70"N	126°26'01.56"E	5 m
814	A	37°27'52.47"N	126°26'20.28"E	6 m
	B	37°27'51.40"N	126°26'21.24"E	6 m
816	A	37°27'47.86"N	126°26'12.13"E	6 m
	B	37°27'46.79"N	126°26'13.08"E	6 m
821	L	37°27'03.14"N	126°27'35.59"E	5 m
	R	37°27'02.29"N	126°27'36.35"E	5 m
831	L	37°26'29.79"N	126°26'49.74"E	5 m
	R	37°26'31.88"N	126°26'47.88"E	5 m
841	A	37°27'23.62"N	126°28'10.93"E	6 m
	B	37°27'22.41"N	126°28'12.00"E	6 m
	C	37°27'22.50"N	126°28'08.93"E	6 m
	D	37°27'21.29"N	126°28'10.01"E	6 m
851	A	37°29'06.79"N	126°26'39.17"E	5 m
	B	37°29'05.55"N	126°26'40.28"E	5 m
	C	37°29'05.65"N	126°26'37.20"E	5 m
	D	37°29'04.43"N	126°26'38.28"E	5 m



INCHEON DEICING	123.575		
PAD CONTROL	121.875 (AS,MS,DS,DN)	122.175 (TC)	122.325 (AN,MN)
ICE MAN	122.225		

Deicing zones operation



Note >
The Pilot stop line marking is located on all deicing pads to help stop without marshalling, where the transverse bar indicates the cockpit stop position. (see figure on the right)

